


Eclipse Wall Mounted Basin Mixer Matte Black

VECL027





Congratulations on your purchase of this high quality product from Voda Plumbingware. Please read the following before installation and retain (along with your receipt) for future reference.

TECHNICAL SPECIFICATIONS

Suitable for All Pressures

Minimum Pressure = 35kPa

Maximum operating Pressure = 500kPa*

Maximum operating Temperature = 65 deg. Celsius

For domestic use only.

CONFIGURATION

Mains Pressure systems Install as supplied.

Unequal Low systems Insert the flat flow restrictor (with the black o-ring facing out) into the cold "C" inlet, and

change Aerator to Low Pressure Aerator.

Equal Low systems Install body as supplied. Change Aerator to Low Pressure Aerator.

INSTALLATION

*FOR PRESSURES EXCEEDING 500kPa INSTALL A PRESSURE REDUCING VALVE. THOROUGHLY FLUSH ALL PIPES TO ELIMINATE ANY REMAINING DIRT AND RESIDUE, AND INSTALL INLINE FILTERS. FAILURE TO DO SO MAY VOID THE WARRANTY.

Before commencing installation turn off the water supply.

- Flush all water lines to remove any foreign materials (so it does not interfere with the flow regulated aerator or damage the cartridge, and install inline filters if not already fitted.
- Make sure that the body recess including wall lining thickness does not exceed 41.5mm to the body centre.
- Note the protrusions at the back of the body to ensure a perpendicular mounting, once screwed into place.
- Install, making sure the spout is on the left. The spout fitment is the final anchor point for the body set.
- Turn on mains supply.
- Check for leaks.

Plumbers Note: Do not pressure test this mixer under static pressure.

ATTACH PROOF OF PURCHASE HERE

WARRANTY

PLEASE CALL US BEFORE REMOVING TAPWARE OR UNDERTAKING ANY REPAIR WORK.

Please refer to our website for warranty information: www.vodaplumbingware.co.nz/warranty

In the unlikely event that this product fails during its warranty period, phone our Customer Service team immediately on 0508 367 366 – as unauthorised removal of the product may void the warranty.

CARE AND MAINTENANCE

SHOULD NOT BE CLEANED WITH ACIDIC, CAUSTIC/ALKALINE, ABRASIVE OR CITRIC CLEANERS.

A soft, damp cloth is recommended for cleaning (Not a Micro fibre cloth). Mild soap solutions can also be used on occasion.