
### **CLEANING**

Water contains lime which remains on the surface after the water has evaporated. These lime deposits can be prevented from forming by wiping immediately after use.


To clean the chrome-plated surface use a soft cloth, soap and warm water. Never use cleaning agents that contain a corrosive acid or a scouring additive.



## NOTES:

### 1) Low and unequal systems:

Removal of the flow restrictor with pliers may be necessary to optimise flow performance in low or unequal pressure systems only. Flow restrictor is lodged firmly in the end of the handset.



Methyen warrants this product against manufacturing defects and that it is suitable for use under the operating conditions specified in this instruction sheet.

For your warranty please refer to www.methven.com or call Customer Service

New Zealand Australia UK 0800 804 222 1300 638 483 0800 195 1602

### 436932 Issue A

# MAKU SATINJET SLIDE RAIL SHOWER **INSTALLATION GUIDE**

### **TECHNICAL SPECIFICATIONS**

### Operating Pressure:

Min 35 kPa, Max 500 kPa. Recommended installation of a pressure limiting valve if supply exceeds 500kPa.

